

Alarm and Flash function command guide

1. Cut With Alarm And Flash

Command(Hex): 1F 1B 1F E0 13 14 m n t mode

m = 00/01, OFF/ON

n: 1<=n<=20, times of alarm and flash.

t: 1<=n<=20, The alarm and flashing interval, it is **t x 50ms**.

Mode = 00/01/02/03,

00: No alarm, no flash;

01: Only alarm, no flash;

02: Only flash, no alarm;

03: Alarm and flash.

Sample:

Turn on cut with alarm and flash, four times, interval is 100ms: **1F 1B 1F E0 13 14 01 04 02 03**.

Turn off cut with alarm and flash: **1F 1B 1F E0 13 14 00 04 02 03**.

2. Ticket Taken Alarm

After cutting if don't take away the ticket within a specified time, printer alarm and flash feature.

Command(Hex): 1F 1B 1F A0 mode toh tol aoh aol

MODE = 00/01/02

00: Trun off;

01: Affter cutting, start the timer;

02: If don't take away the ticket, and have a new ticket and cutting(second cutting), alarm and flash immediately without waiting.

TOH TOL: Ticket taken alarm timeout, unit is **seconds**, default is **10s**. If you set 0s, alarm and flash immediately without waiting.

AOH AOL: Alarm and flash timeout, unit is **seconds**, default is **300s**. If you set 0s, no timeout, printer alarm and flash until take away the ticket.

Sample:

Trun off: **1F 1B 1F A0 00 00 05 00 05**

Alarm after 5 seconds: **1F 1B 1F A0 01 00 05 00 05**

Alarm after 10 seconds: **1F 1B 1F A0 01 00 0A 00 05**

How to use it?

Setting tool(Printer test V3.1) download: https://drive.google.com/open?id=1IAZ7DVXYIkYFZMPiG61i2Ua4_sOkE65U

Printer test V3.1

×

Port Select

☐ LPT ☐ COM ☒ USB ☐ NET

Printer Type

☐ POS-58 ☐ POS-76 ☒ POS-80

LPT Settings

LPT1

COM Settings

COM1

9600

RTS

NET Set

Local IP:

192 . 168 . 56 . 1

Refresh

Auto Set Ip

Printer IP:

192 . 168 . 11 . 175

Connect

Ping

New IP:

192 . 168 . 1 . 100

Set New IP

NetMonitor

New ID:

0 . 0 . 0 . 0

New ID

(Set last four ID)

Content: ☐ NO. Rep: 1 ☒ HEX Clear ☐ AutoSend Cyc 500 ms ☐ CutPaper

1 2 3

1F 1B 1F A0 01 00 05 00 05

1

2

3

Print

Cut Paper


Open cash drawer

Traditional

Driver Print

Advanced

中文简体

 POS printer test tool V3.1

☐ 2019-03-29 11:43:59

USB printer is remove from the computer!